

Reset	GND
DAC 2	VDDA
5.1	RS232 RX
Bufr 2	RS232 TX
5.3	3.2
5.5	3.3
1.0	3.4
1.1	DAC 1
1.2	Ext.Trig
1.3	pGen
ADC 1	MOSI
ADC 2	MISO
User EN 1.6	CS
ADC Byp 1.7	spi
2.0	4.4
2.1	4.5
2.2	4.6
High Byte	SCL
2.3	SDA
2.4	I <sup>2</sup> C
2.5	0.0
2.6	0.1
2.7	0.2
6.0	Low Byte
6.1	0.3
6.2	0.4
6.4	0.5
6.5	0.6
GND	User switch 0.7
VDDIO	GND
	VDDD